

LEVELAB

User Guide

Contents

About LEVELAB.....	2
Before Use	3
Application Structure & License Authentication	3
System Requirements.....	3
Supported Devices	3
Installation	4
Download.....	4
Placing the Application in Any Folder	4
Connecting the USB Dongle.....	4
Startup.....	5
Settings.....	5
LEVELNIC Settings.....	6
System Settings	7
Straightness Graph Color Settings	8
Flatness Graph Color Settings	9
About This Application	10
Flatness Measurement	11
Measurement Condition Screen	12
Measurement Screen	14
Measurement Result Screen.....	15
Straightness Measurement.....	18
Measurement Conditions / Measurement Screen.....	19
Measurement Result Screen.....	20

About LEVELAB

LEVELAB is an application for measuring the accuracy of surface plates and machine tools.

By using it together with our digital level **LEVELNIC**, you can easily measure flatness and straightness.

Even when measuring displacement with a dial gauge or similar, you can enter values using the keyboard and compute flatness or straightness.

Before Use

Application Structure & License Authentication

LEVELAB can be used as-is, but connecting our dedicated **USB dongle** to your computer unlocks restricted features and allows access to additional functions.

The USB dongle includes licenses for each measurement function.

Connecting a currently sold USB dongle unlocks **flatness** and **straightness** measurements.

In LEVELAB:

- Authenticated via USB dongle → **Full Edition**
- Not authenticated → **Trial Edition**

System Requirements

- Windows 10 (32-bit / 64-bit)
- Windows 11
- *ARM-based Windows is not supported.*

Supported Devices

LEVELAB can be used conveniently with LEVELNIC devices.

Compatible models include:

- DL-m5W
- DL-m5
- DL-m4M
- DL-mini
- DL-S2W
- DL-S3L
- DL-S3
- DL-S4W
- DL-mXY (usable by switching to 1-axis mode)
- DL-SXY (usable by switching to 1-axis mode)

Both **wired** and **wireless** connections are supported.

Installation

Download

The application can be downloaded from the LEVELAB page on our website:

https://www.niigataseiki.co.jp/software_levelab/

Download the appropriate version for your computer and extract the files after downloading.

Placing the Application in Any Folder

No installation is required.

Double-click the executable to run it.


Because settings files and folders are created on first launch, we recommend keeping the application in the **same folder** at all times.

Connecting the USB Dongle

If you have purchased a USB dongle, connect it **before launching** the application.

Only **one dongle** should be connected when starting LEVELAB.

Startup



When the application is launched, the **Start Page** appears.

You can navigate to each measurement function from this screen.

Settings

We recommend configuring settings after the first startup.

LEVELNIC Settings

Select LEVELNIC

Select the LEVELNIC device you will use for measurement from the list.

Port Settings

Select the COM port used by the LEVELNIC.

When the connection is recognized, the available ports will appear in the list upon selection.

If “Other” is selected as the LEVELNIC type, choose the correct baud rate that matches the connected device.

Data Acquisition Timing

Choose whether to acquire data by clicking a button in the application or by pressing the data output button on the LEVELNIC.

Note: Depending on the LEVELNIC model and data acquisition method, the switch settings on the LEVELNIC may need to be changed.

System Settings



Font Size

The font size can be changed in 5 levels.


Startup Page

The default is the "Start Page." You may change it so that a measurement screen opens immediately at startup.

Sound Settings


Beep sounds can be enabled for errors and data acquisition.

Straightness Graph Color Settings



You can change the color of elements displayed in the straightness result graph (straightness line, auxiliary lines, etc.).

Flatness Graph Color Settings



You can change the color of elements displayed in the flatness result graph (reference plane, measurement lines, etc.).

About This Application



You can check the current version and edition of LEVELAB.

By clicking “Check for Updates,” you can see whether an update is available.

If an update exists, a notice will appear.

Flatness Measurement

Flatness is calculated by entering tilt values measured with a level (mm/m) or displacement values measured with a dial gauge (μm).

Two input methods are available:

1. Import data from LEVELNIC
2. Enter manually from keyboard using recorded measurements

Using a level:

Two points corresponding to the measurement pitch are measured sequentially.

If the far end in the measurement direction is higher → positive value

If lower → negative value

Using a displacement gauge:

A reference straightedge is assumed to be a perfect line, and displacement from it is measured.

If the probe moves upward → positive

If downward → negative

Measurement Condition Screen

The screenshot shows the '01 計測設定' (Measurement Setting) tab. At the top, there's a header with three tabs: '01 計測設定', '02 測定データ入力', and '03 測定結果'. Below the header, a message says '既存データから設定を取り込む' (Load settings from existing data). There are two main sections: '計測データファイルを選択' (Select measurement data file) and 'テンプレートを選擇' (Select template). The '計測データファイルを選択' section has a file input field and a '読み込む' (Load) button. The 'テンプレートを選擇' section has a dropdown menu and a '削除' (Delete) button. Below these, there's a section for '手動で設定を入力する' (Enter settings manually), which includes '入力方法' (Input method) with radio buttons for 'LEVELNIC' and 'キーボード入力' (Keyboard input). The 'LEVELNIC' section has a 'LEVELNIC設定' (LEVELNIC settings) area with a 'COM' field and a 'LEVELNICの設定を変更' (Change LEVELNIC settings) button. The 'キーボード入力設定' (Keyboard input settings) section has radio buttons for '水準器測定値 (mm/M)' (Leveling instrument measurement value) and '変位測定値 (um)' (Displacement measurement value). The '計測方法' (Measurement method) section has four buttons: '井桁法' (Grid method), '3点測定法' (3-point method), '対角線法' (Diagonal method), and '井桁法+対角線法' (Grid + Diagonal method). The '計測設定' (Measurement settings) section has three columns of input fields for '横方向分割数' (Horizontal division), '縦方向分割数' (Vertical division), and '対角線分割数' (Diagonal division), each with a 'mm' unit. At the bottom, there's a 'テンプレート名' (Template name) field, a checkbox for 'この内容を設定テンプレートとして保存する' (Save this content as a setting template), and buttons for 'データクリア' (Clear data) and '計測設定の確認' (Confirm measurement settings).

Input Method

Select whether to measure using LEVELNIC or enter recorded values by keyboard.

Keyboard Input Type

If keyboard input is selected, choose whether the values are:

- Tilt values from a level
- Displacement values from a dial gauge, etc.

Measurement Method

Choose one of four methods:

- Grid Method
- 3-Point Method
- Diagonal Method
- Grid + Diagonal Method

If entering displacement values:

- Only **Diagonal** or **Grid + Diagonal** can be used.

Measurement Settings

Specify division counts and measurement pitch.

- Max divisions (horizontal/vertical/diagonal): **50** (Trial Edition: **3**)
- Measurement pitch: **10–1000 mm**

Templates

Measurement conditions (method, input type, settings, etc.) can be saved as templates.

(Templates cannot be used in Trial Edition.)

To save, check the box **“Save these conditions as a measurement template.”**

Templates can be deleted with the “Delete” button.

Measurement Data File

Load previously measured data (contains measurement values).

(Not available in Trial Edition.)

Supported extensions: **.fid, .json**

Loaded data is restored exactly and cannot be modified.

Clear Data

Deletes all currently entered data.

Measurement Screen

The screenshot displays the 'Measurement Screen' with three main tabs: '01 計測設定' (Measurement Settings), '02 測定データ入力' (Measurement Data Input), and '03 測定結果' (Measurement Results). The '02 測定データ入力' tab is active, showing a '測定データ入力' (Measurement Data Input) section with two tables for '横方向測定' (Horizontal Measurement) and '縦方向測定' (Vertical Measurement). Each table has columns for '01', '02', and '03'. To the right of these tables are buttons for '表データをコピー' (Copy Table Data) and '全てのデータを消去' (Delete All Data). On the far right, a diagram shows a grid of points with a green line indicating a measurement path. Below the diagram, the '入力方法' (Input Method) is set to 'キーボード入力' (Keyboard Input), and the '計測方法' (Measurement Method) is '井桁法' (Grid Method). The '計測設定' (Measurement Settings) section lists parameters: '横方向分割数(1~50): 3', '横方向測定ピッチ(10~1000): 10mm', '横方向測定全長: 30mm', '縦方向分割数(1~50): 3', '縦方向測定ピッチ(10~1000): 10mm', and '縦方向測定全長: 30mm'. At the bottom, the 'ワーク情報入力' (Workpiece Information Input) section includes fields for 'ワーク名' (Workpiece Name), 'No.', and '測定者名' (Measurer's Name), with buttons for 'データ保存' (Save Data) and '計算結果の表示' (Display Calculation Results).

On this screen, you enter the measurement values.

- For **keyboard input**, enter values directly into the displayed cells.
- For **LEVELNIC input**, values are entered automatically when acquisition is triggered.

To record workpiece information, enter:

- Workpiece Name
- Workpiece No.
- Measurer's Name

Notes Regarding Each Measurement Method

Grid Method

- Horizontal lines: Zero adjustment is allowed at each starting point, but **not allowed during measurement**.
- Vertical lines: Zero adjustment is allowed at the left starting point, but **not allowed during measurement**.
- Right-side vertical measurement lines: Zero adjustment is **not allowed**, even at the starting

point.

Diagonal Method

- Zero adjustment is allowed at the start point of each horizontal, vertical, and diagonal line, but **not allowed during measurement**.


Grid + Diagonal Method

- Same rules as above: Zero allowed at start points only.

3-Point Method

- Horizontal lines: Zero adjustment is allowed **only** at the start of the first horizontal line. After that, zero must **not** be adjusted until all horizontal lines are completed.
- Vertical lines: Zero adjustment is allowed at the start point only, but not during measurement.

Measurement Result Screen



Measurement values are calculated and displayed as:

- Numerical values

- Graphs

The **maximum value** is marked with *

The **minimum value** is marked with @

These points are shown as *thicker vertical bars* in the graph.

Display Modes

Three-Point Zero Reference

The upper-left, lower-left, and upper-right corners are set to 0 μm .

Displays how other points deviate above or below these references.

Diagonal Equal-Height Reference

The upper-left and lower-right corners are set to 0 μm ;

The remaining diagonal points are leveled to equal height.

The difference between max and min becomes the **maximum deviation**.

Minimum Zone Reference

The upper-left corner is set to 0 μm , and the measured plane is rotated to minimize the difference between highest and lowest values.

This minimized difference becomes the **flatness**.

(This corresponds to the minimum separation between two parallel planes.)

Center Zero (for Diagonal or Grid+Diagonal methods)

When checked, the diagonal crossing point is used as the 0 μm reference.

For Grid+Diagonal method:

Ideally, the center point derived from the cross measurement and the diagonal measurement should match.

But due to errors (probe placement, instrument precision, pitch accumulation), differences may occur, and up to **three center values** are shown.

Maximum Deviation / Flatness

Difference between max and min of the selected display mode.

“Flatness” is shown only when **Minimum Zone** is selected.

Rounding Note

Displayed values are rounded to the next lower digit.

Maximum deviation/flatness is rounded after difference computation, so a 1-digit mismatch may occur—this is normal.

Scale

You may specify the graph's full vertical scale.

"0" enables auto-scaling.

Printing

Prints the measurement results.

(Not available in the Trial Edition.)

Press "Print Calculation Results" and follow the instructions.

Straightness Measurement

Straightness is obtained by entering tilt values measured with a level (mm/m) or displacement values measured with a dial gauge (μm).

As with flatness:

- Data may be imported from LEVELNIC
- Or entered manually by keyboard

Using a level:

Two points at the measurement pitch are measured sequentially.

Positive \rightarrow far end is higher

Negative \rightarrow far end is lower

Using a displacement gauge:

A reference straightedge is treated as an ideal straight line.

Upward probe movement \rightarrow positive

Downward \rightarrow negative

Measurement Conditions / Measurement Screen

01 計測設定 & 測定データ入力

既存データから設定を取り込む 既存の測定データを引き継ぐことができます

計測データファイルを選択 拡張子: .sid, .json

ファイル選択(.XX) 読み込む

手で設定を入力する 入力方法と設定数値を入力してください

入力方法

☒ LEVELNIC ☐ キーボード入力

LEVELNIC設定

COM: LEVELNIC: データ取り込みタイミング: コンピュータで指示

LEVELNICの設定を変更

キー入力設定

☒ 水準器測定値 [mm/M] ☐ 変位測定値 [μm]

データ情報

データ数 測定ピッチ (10~1000)

0 mm

データ入力

	001	002	003	004	005	006	007	008	009	010	011
測定値 [mm/M]											

LEVELNIC入力

取り込み

ワーク情報入力

ワーク名 No. 測定者名

データクリア データ保存 測定を開始

Input method, keyboard input settings, and workpiece information are the same as in flatness measurement.

Maximum Number of Points

- Up to **300** measurement points
- Trial Edition: **10**

Note for Displacement (μm) Input


The first cell represents the displacement at the **first measurement point** a full pitch away from the starting point.

The starting point is assumed to be adjusted to **0 μm**.

Measurement Pitch

Enter an integer between **10–1000 mm**.

Measurement Result Screen



After completing measurement, results are displayed for:

- Straightness
- Start-end zero alignment

Computation Data

Cumulative Height

If LEVELNIC was zeroed to horizontal, values show heights relative to horizontal.

If zeroed at the measurement start point, values show heights relative to the extension of that slope.

If displacement gauge input is used:

- Height is inherently measured
- Cumulative height is not calculated (shown as ***)

Start-End Zero

Cumulative heights are recalculated so that the end point becomes zero.

Shows how intermediate points vary.

The difference between max and min becomes the **maximum deviation**.

Straightness

Cumulative heights are compensated (tilt-adjusted) to minimize the difference between max and min.

(This corresponds to fitting the measurement between two parallel straight lines with minimum separation.)

The difference between max and min becomes the **straightness**.

Measurement Information

Straightness

Difference between the maximum and minimum of the straightness values.

Maximum Deviation

Difference between the max and min of the start-end zero values.

Total Measurement Length

Measurement pitch \times number of measurements.

Slope (Straightness Compensation)

The slope adjusted during straightness compensation.

Internally calculated with high precision, but displayed rounded to 0.001.

Slope (Start-End Zero Compensation)

The slope adjusted for start-end zero alignment (also rounded to 0.001).

Even if straightness and start-end zero values differ, the slopes may match due to rounding.