


精密測定工具 デジタルオフセットノギス

この度は「デジタルオフセットノギス」をお買い上げいただきありがとうございます。この商品は、段差のある箇所での外側・内側測定が可能な精密測定工具です。ジョウを上下にスライドさせることで安定した段差測定ができます。

- 正しく安全にお使いいただくため、ご使用前に本取扱説明書を必ず読み、記載の手順に従ってご使用ください。お読みになった後は、お使いになる方がいつでも見ることができる場所に大切に保管してください。
- 第三者に譲渡・貸与される場合も、この説明書を必ず添付してください。
- 当商品に関するお問い合わせは、お買い求めの販売店もしくは当社にご連絡ください。

■各部の名称と機能



- ①外側用測定面 …… 被測定物をこの面で挟んで測定します。
- ②外側用ジョウ …… 被測定物の外側を測ります。
- ③ジョウ止めねじ …… 左側のジョウを固定します。
- ④内側用ジョウ …… 被測定物の内側を測ります。
- ⑤内側用測定面 …… 被測定物の内側にこの面を当てて測定します。
- ⑥LCD表示部 …… 測定数値をデジタル表示します。
- ⑦止めねじ …… デジタル液晶部のスライドを固定します。
- ⑧HOLDスイッチ …… 押すと画面上に"HOLD"と表示され、表示している数値を固定できます。
- ⑨出力コネクタ …… 別売の Bluetooth BOX を接続することで、測定値をパソコンへ出力することができます。
- ⑩本尺 …… デジタル液晶部のスライドを保持します。
- ⑪電池蓋 …… 開けて電池をセットします。
- ⑫ZEROスイッチ …… 押すと画面数値が"0.00"と表示されます。
- ⑬ON/OFFスイッチ …… 電源のON/OFFを行います。

安全上のご注意 必ずお守りください

お使いになる人や他の人への危害、財産への損害を未然に防止するため、必ずお守りいただくことを右記のように説明しています。

してはいけない内容『**禁止事項**』です。

必ず実行していただく内容『**強制事項**』です。

注意 お守りいただかないと『**傷害を負う、または物的損害が発生するおそれがある内容**』です。

- 取扱説明書をよく読み、指示に従う。**
・取扱説明書に記載された内容以外での使用は、事故の原因となります。
- 測定作業にのみ使用する。**
・指定用途以外へのご使用は、製品の破損や磨耗、予測できない事故の原因となります。
- 大切に取り扱い扱う。**
・ぶつける、落とすなどの衝撃を与えたり、重量物を上に乗せたりしないでください。精度不良や破損の原因となります。
- ・商品に傷をつけないでください。
- インバータ式蛍光灯などの電界が発生する場所での使用は避ける。**
・LCD表示部の数値が誤作動を起こす原因となります。

- 下記の条件を満たす環境で使用・保管する。**
●雨や水、油などがつかからない、乾燥した場所
●高温にならない場所
●子どもや、使用者以外が近付かない場所
・上記に反する場所での使用は製品の破損、事故やけがの原因となります。
- ジョウ先端は尖っているため、扱いに注意する。**
・けがの原因となります。
- 分解・改造を行わない。**
・製品の破損や事故の原因となります。修理はお買い上げの販売店、または当社までご連絡ください。
- 電気ペンなどで書き込まない。**
・電気ペンなどで本尺やジョウなどに、番号などの書き込みをしないでください。


使用前の準備

ご使用前に、下記の準備を行ってください。

- 測定面、摺動面、外観などの汚れや防錆油などを拭き取るそのまま測定を行うと誤差の原因となります。
- 本体と被測定物の温度慣らしを十分に行う
測定器本体と被測定物の間に温度差があると、誤差の原因となります。同じ温度になるよう、温度慣らしは十分に行ってください。

電池のセット・交換


- ①電池蓋を矢印の向きに開けます。
- ②電池を、必ず(+)側を表にしてセットしてください。
- ③電池蓋を元通りに装着してください。



△ご注意 電池は必ずCR2032をお使いください。

●電池をセットする際は、端子の折れにご注意ください。

- ・電池をセットする際に上から強く押し込むと、端子が折れて破損する場合があります。
- ・電池をセットする際は、右斜め方向から端子を外側に押すように、本体のツメの下へ入れ込んでください。



使用後のお手入れ・保管方法

- 測定面・摺動面・外観などの汚れや油などを乾いたウエスで拭き取り、防錆処理を行う
防錆処理は防錆油を薄く塗るか、防錆袋などに入れてください。
- 止めねじをゆるめた状態で保管する
止めねじを締めて固定すると、温度変化による膨張などで無理な力がかかり、精度不良の原因となります。
- 付属のケースに入れ、乾燥した冷暗所に保管する
直射日光や湿気は避け、管理者以外が触れない状態で保管してください。
- 長期間使用しない場合は電池を製品から取り外した状態で保管する

トラブルと対応

- Q. LCD表示部に何も表示されない。
A. 電池の残量が少なくなっている可能性があります。新しい電池と交換してください。
- Q. 電源ONの状態でもスライドさせてもLCD表示の数字が変わらない。
A. 一度電池を取り外し、30秒後に電池をセットし直してください。
- Q. スイッチを押しても何も反応しない。
A. 電池が正しくセットされているか確認してください。
- Q. LCD表示部に『MAX』『MIN』『△』などの文字が表示されている。
A. 一度電源を切るか、HOLDスイッチを何回か長押しして文字を消してからご使用ください。
- Q. 正しい数値が表示されない。
A. 使用環境の湿度が高い可能性があります。本器を乾燥させ、湿度が低い環境下でご使用ください。

使用方法

■電源のON/OFF

- ①電源をONにするには、「ON/OFF」スイッチを押してください。
- ②電源をOFFにするには、「ON/OFF」スイッチを押してください。
- ③電源ONの状態から「HOLD」スイッチを押すと数値が固定されます。

■絶対測定モード


- ①止めねじをゆるめ、電源を入れてください。
- ②ノギスのジョウを閉じた状態で「ZERO」スイッチを押してください。
- ③LCD表示部に"0.00mm"が表示されると計測開始OKです。

■比較測定モード

- ①止めねじをゆるめ、電源を入れてください。
- ②ノギスのジョウが開いた状態で「ZERO」スイッチを押してください。
- ③LCD表示部に"0.00mm"が表示されると計測開始OKです。

■ジョウの位置調整

ジョウ止めねじをゆるめ、測定物の段差に合わせてジョウの位置を調整して固定し、使用してください。



修理の際は

- 正常に作動しない場合や、不明な点がございましたらお買い上げの販売店または、当社までご連絡ください。
- お問い合わせや、ご連絡が無いまま直接当社に修理品などを送付されても処理、対応ができない場合がありますのでご了承ください。

製品仕様

- ・測定範囲: 0 - 150mm
- ・最大許容誤差: ±0.04mm
※量子化誤差 (±1カウント含まず)
- ・最小読取値: 0.01mm
- ・表示: LCD 5桁表示
- ・オートオフ: 約20分
- ・最大応答速度: 右方向へのスライド…1.5m/s
左方向へのスライド…0.75m/s
※右方向、左方向は各部の名称の図を正面にした場合
- ・使用温度範囲: 0℃～40℃
- ・保管温度範囲: -10℃～60℃
- ・電源: リチウム電池 CR2032×1
- ・電池寿命: 通常使用状態で約2.5年
- ・質量: 230g
- ・付属品: リチウム電池 CR2032 (テスト用)


DIGITAL OFFSET CALIPERS

Thank you for purchasing Niigata Seiki Digital Offset Calipers.

This is a precision measuring tool for measuring inside and outside dimensions when there is a step or offset between surfaces. Jaw can be adjusted to match workpiece for accurate measurements.

- For safe and proper use, please read this instruction manual before use and follow the procedures described. Please keep manual where it is accessible to user for future reference.
- Keep this manual with the instrument if transferred or leased to a third party.
- For inquiries about this product, please contact dealer or Niigata Seiki.

■ PART IDENTIFICATION AND FUNCTION



- | | |
|---|---|
| ① Measuring Surfaces for outside measurements | Object to be measured is positioned between these surfaces. |
| ② Outside Jaws | For measuring outside dimensions. |
| ③ Jaw Clamp Screw | Secures the adjustable jaw in position. |
| ④ Inside Jaws | For measuring inside dimensions. |
| ⑤ Measuring surfaces for inside measurements | Position surfaces inside object to be measured. |
| ⑥ LCD Display | Displays digital measurement. |
| ⑦ Lock Screw | Tighten to prevent the slide and display from moving. |
| ⑧ [HOLD] Button | When pressed, "HOLD" icon appears on Display and measurement will be fixed. |
| ⑨ Output Connector | Connect to optional Bluetooth Box to send measurements to PC. |
| ⑩ Scale | Supports LCD Display Unit. |
| ⑪ Battery Cover | Open to access battery. |
| ⑫ [ZERO] Button | When pressed, Display will read "0.00". |
| ⑬ [ON/OFF] Button | For turning power ON / OFF. |

SAFETY PRECAUTIONS

Please Observe

To prevent harm to yourself or others, and to prevent damage to property, always follow the procedures marked by the following symbols.



Denotes a prohibition - **You MUST NOT do**



Denotes a requirement - **You MUST do**

⚠ WARNING Indicates risk of personal injury or property damage if not followed.

- | | |
|---|--|
| <ul style="list-style-type: none"> ● Read the manual and follow the directions. <ul style="list-style-type: none"> • Use of product other than as described in this manual may cause accident. ● Use only for measuring. <ul style="list-style-type: none"> • Use for any purpose other than measuring may damage or wear the instrument. Improper use may also cause accident. ● Handle with Care. <ul style="list-style-type: none"> • Do not drop or subject instrument to excessive shock. Do not place under heavy objects. Improper handling may cause damage or poor accuracy. • Do not scratch instrument, for example by writing ID number. ● Avoid using in high electric fields, such as near fluorescent lights or switching power supplies. <ul style="list-style-type: none"> • Incorrect value may be displayed on LCD. | <ul style="list-style-type: none"> ● Use and store only in environment meeting the following conditions: <ul style="list-style-type: none"> ● Dry location protected from rain, water, and oils. ● Location that is not excessively hot. ● Location protected from use by children and unauthorized people. • Use in places contrary to the above may cause damage to the product resulting in accident or injury. ● Jaw Tips Are Sharp—Handle With Care. <ul style="list-style-type: none"> • Careless handling may cause injury. ● Do not disassemble or modify. <ul style="list-style-type: none"> • Disassembly may damage product or cause accident. For repair, please contact distributor. ● Do not write on instrument with electric engraver. <ul style="list-style-type: none"> • Do not engrave instrument body or jaw, such as an ID number with engraver or electric pen. |
|---|--|


PREPARATION FOR USE

Before using the caliper, please follow the steps below:

- **Wipe off rust proofing and dirt from measuring surfaces and slide.**
 - Contamination of surfaces may cause measurement error.
- **Allow the caliper and object to be measured time to reach the same temperature.**
 - A temperature difference between the object to be measured and the caliper may cause measurement error. Allow enough time for the temperatures to equilibrate.


INSERTING • REPLACING BATTERY

- ① Slide cover in direction of arrow.
- ② Insert battery with (+) side outward.
- ③ Replace battery cover.



⚠ Notice Use only CR2032 type battery

- **Use care to avoid damaging terminals when inserting battery**
 - Terminals may be broken if battery is pressed straight down.
 - Insert battery at angle, underneath the small hook, as shown.



AFTER USE CARE • STORAGE

- **After use, wipe off any dirt or oil from measuring surfaces, sliding surfaces, and exterior using a dry cloth and perform rust prevention treatment.**
 - For rust prevention, lightly apply anti-rust oil, or place in rust preventive bag.
- **Store with Lock Screws loosened.**
 - If stored with Lock Screws tight, expansion due to temperature changes may cause excessive force which will cause inaccuracy.
- **Store in a cool, dry, and dark location in the provided case.**
 - Keep out of direct sunlight and moisture, and please keep secure from unauthorized personnel.
- **Remove battery if Caliper will not be used for a long period of time.**

TROUBLESHOOTING

- Q. **Nothing is displayed on LCD.**
 - A. The battery may be running low, please replace battery with a new one.
- Q. **With power on, the number on the LCD does not change as Display Unit is moved.**
 - A. Please reset by removing battery for about 30sec., and then replacing.
- Q. **Nothing happens when buttons are pressed.**
 - A. Make sure battery is properly inserted.
- Q. **The characters "MIN", "MAX", or "△" are displayed on LCD.**
 - A. Cycle power, or apply several long presses to [HOLD] Button. Use as normal once character is off.
- Q. **The correct value is not displayed.**
 - A. High humidity may cause dampness. Please dry off the instrument and use only in dry location.

HOW TO USE

■ Power ON/OFF

- ① To turn on, press the [ON/OFF] Button.
- ② To turn off, press the [ON/OFF] Button.
- ③ With power on, press the [HOLD] Button to fix the value on the display.

■ Absolute Measurement Mode


- ① Loosen the Lock Screw and turn power ON.
- ② With jaws closed, press the [ZERO] Button.
- ③ When "0.00mm" is displayed on LCD, Caliper is ready to start measurement.

■ Comparison Measure Mode

- ① Loosen the Lock Screw and turn power ON.
- ② With jaws open to desired reference position (any point is OK.) press [ZERO] Button.
- ③ When "0.00mm" is displayed on LCD, Caliper is ready to start measurement.

■ Adjusting the Jaw Position

Loosen the Jaw Clamp Screw and adjust the Jaw for the desired position and re-tighten to use.



SERVICE

- If Instrument is not working properly, or if you have any questions, please contact distributor.
- Please note, manufacturer is unable to respond to inquires or provide service directly. Please contact distributor.

SPECIFICATIONS

- Measurement Range : 0 - 150mm
- Maximum Permissible Error : ±0.04mm
 - ※Not including quantization error (±1count)
- Resolution : 0.01mm
- Display : 5 Digit LCD
- Auto Off : approx. 20 min.
- Maximum response speed : Slide to Right 1.5 mm/s
 - Slide to Left 0.75 mm/s
 - ※Left/Right as shown in diagram at top of manual.
- Operating Temperature Range : 0°C~40°C
- Storage Temperature Range : -10°C~60°C
- Power : (1x) CR2032 Lithium Battery
- Battery Life : approx. 2.5 years in normal use.
- Weight : 230g
- Accessory : CR2032 Lithium Battery (for test)